

SBE 19plus V2 SEACAT Profiler Reference Sheet

(see SBE 19plus V2 User's Manual for complete details)

Sampling Modes

- **Profiling (MP)** – Vertical profiles, sampling at 4 Hz. SBE 19plus V2 runs continuously.
- **Moored (MM)** – Time series measurements once every 10 seconds to once every 4 hours. SBE 19plus V2 powers down between samples.

Communication Setup Parameters

1. Double click on SCPlusV2_RS232.exe.
2. Once main screen appears, in the Serial Port menu, select Configure. Select the Comm port and baud rate (factory set to 9600), and click OK.
3. The terminal program should automatically connect to the 19plus V2. As it connects, it sends **GetHD** and displays the response, and then fills the Send Commands window with the list of commands for your 19plus V2.

Deployment

1. Batteries:
 - A. *Remove battery end cap:* Wipe dry housing/end cap seam. Unthread end cap by rotating counter-clockwise. Wipe dry O-ring mating surfaces in housing with lint-free cloth.
 - B. *Remove and replace battery cover plate and batteries:* Remove three Phillips-head screws and washers from battery cover plate, and remove cover plate. Turn SBE 19plus V2 over and remove batteries. Install new batteries, + terminals against flat contacts and - terminals against spring contacts. Align battery cover plate with housing. Reinstall three Phillips-head screws and washers, while pushing hard on battery cover plate to depress spring contacts at bottom of battery compartment.
 - C. *Reinstall battery end cap:* Remove water from O-rings and mating surfaces with lint-free cloth. Inspect O-rings and mating surfaces for dirt, nicks, and cuts. Clean/replace as necessary. Apply light coat of O-ring lubricant to O-ring and mating surfaces. Fit end cap into housing and rethread into place, using a wrench to ensure end cap is tightly secured.
2. Program SBE 19plus V2 for intended deployment (see other side of this sheet for *Command Instructions and List*):
 - A. Send **DateTime=mmddyyhhmmss** (month, day, year, hour, minute, second) to set date and time.
 - B. Ensure all data has been uploaded, and then send **InitLogging** to make entire memory available for recording. If **InitLogging** is not sent, data will be stored after last recorded sample.
 - C. Establish setup and logging parameters. If desired, use **StartDateTime=** and **StartLater** to establish delayed start date and time for Moored mode or (if **IgnoreSwitch=Y**) for Profiling mode.
3. Install a cable or dummy plug for each connector on SBE 19plus V2 sensor end cap. Install a locking sleeve over each plug/cable connector. Connect other end of cables to appropriate sensors.
4. Verify hardware and external fittings are secure.
5. Remove Tygon tubing that was looped end-to-end around conductivity cell for storage. Reconnect Tygon tubing from pump to conductivity cell.
6. To start logging in **Profiling mode** –
 - (if **IgnoreSwitch=N**) Turn on magnetic switch;
 - (if **IgnoreSwitch=Y**) If not already done, send **StartNow** or send **StartDateTime=** and **StartLater**;
 - (if **AutoRun=Y**) Turn on power.
7. To start logging in **Moored mode** - If not already done, send **StartNow** or send **StartDateTime=** and **StartLater**.

Command Instructions and List (see manual for complete list and descriptions)

- Input commands in upper or lower case letters and register commands by pressing Enter key.
- 19plus V2 sends an error message if an invalid command is entered.
- (if **OutputExecutedTag=N**) If 19plus V2 does not return S> prompt after executing a command, press Enter key to get S>.
- If new command is not received within 2 minutes after completion of a command, 19plus V2 returns to quiescent (sleep) state.
- If in quiescent (sleep) state, re-establish communications by clicking Connect in Serial Port menu or pressing Enter key.

Category	Command	Description
Status	GetCD	Get and display Configuration Data.
	GetSD	Get and display Status Data.
	GetCC	Get and display Calibration Coefficients.
	GetEC	Get and display Event Counters.
	ResetEC	Reset Event Counters.
	GetHD	Get and display Hardware Data.
	DS	Display status and setup parameters.
General Setup	DCal	Display calibration coefficients.
	DateTime=mmddyyyyhhmmss	Set real-time clock month, day, year, hour, minute, second
	BaudRate=x	x= baud rate (600, 1200, 2400, 4800, 9600, 19200, 33600, 38400, 57600, 115200). Default 9600.
	Echo=x	x=Y: Echo characters as you type. x=N: Do not.
	OutputExecutedTag=x	x=Y: Display XML Executing and Executed tags. x=N: Do not.
	BatteryType=x	x=alkaline: Alkaline. x=nicad: Nickel-Cadmium. x=nimh: Nickel Metal Hydride.
	InitLogging	After uploading data, initialize logging to make entire memory available for recording.
	SampleNumber=x	After uploading data, set SampleNumber=0 to make entire memory available for recording.
Pressure & Voltage Sensor Setup	HeaderNumber=x	x= header and cast number for first cast when logging begins.
	QS	Place SBE 19plus V2 in quiescent (sleep) state. Logging and memory retention not affected.
	PType=x	x=1: Strain-gauge pressure. x=3: Quartz pressure.
	Volt0=x Volt1=x Volt2=x Volt3=x Volt4=x Volt5=x	x=Y: Enable external voltage (voltage 0, 1, 2, 3, 4, and 5). x=N: Do not.
RS-232 Sensor Setup	BioWiper=x	x=Y: Configuration includes ECO-FL fluorometer with Bio-Wiper. x=N: Does not.
	SBE38=x	x=Y: Enable SBE 38 secondary temperature sensor. x=N: Do not.
	GTD=x and DualGTD=x	x=Y: Enable 1 or 2 GTDs (Pro-Oceanus Gas Tension Device). x=N: Do not.
Output Format	TGTD	Measure Gas Tension Device(s), output 1 converted data sample for each GTD.
	SendGTD=command	Send command to GTD (any command recognized by GTD) and receive response.
	OutputFormat=x	x=0: Raw, Hex. x=1: Converted, Hex. x=2: Raw, decimal. x=3: Converted, decimal. x=4: Pressure and scan number, Hex. x=5: Converted, decimal, XML.
	OutputSal=x	x=Y: Output salinity (psu). x=N: Do not.
Profiling Mode Setup (no effect if in moored mode)	OutputSV=x	x=Y: Output sound velocity (m/sec). x=N: Do not.
	OutputUCSD=x	x=Y: Output sigma-t (kg/m ³), battery voltage, operating current (mA). x=N: Do not.
	MP	Set to Profiling mode.
	NAvg=x	x= number of samples to average. Default 1. Must be even number (2, 4, etc.) if 19plus V2 includes optional Quartz pressure sensor.
	MinCondFreq=x	x= minimum conductivity frequency (Hz) to enable pump turn-on.
	PumpDelay=x	x= time (seconds) to wait after minimum conductivity frequency reached before turning pump on.
Moored Mode Setup (no effect if in profiling mode)	AutoRun=x	x=Y: Start / stop logging when external power applied / removed. x=N: Do not.
	IgnoreSwitch=x	x=Y: Ignore switch for starting/stopping logging. x=N: Do not.
	MM	Set to Moored mode.
	SampleInterval=x	x = interval (seconds) between samples (10 - 14,400).
	NCycles=x	x= number of measurements to take and average every SampleInterval seconds. Must be even number (2, 4, etc.) if 19plus V2 includes optional Quartz pressure sensor).
	MooredPumpMode=x	x=0: No pump. x=1: Run pump for 0.5 seconds before each sample. x=2: Run pump during each sample.
	DelayBeforeSampling=x	x= time (seconds) to wait after switching on external voltage before sampling.
Logging	ParosIntegration=x	x= integration time (seconds) for optional Quartz pressure sensor (1 - 600; default 1).
	MooredTxRealTime=x	x=Y: Output real-time data. x=N: Do not.
	StartNow	Start logging now.
	StartDateTime=mmddyyyyhhmmss	Delayed logging start: month, day, year, hour, minute, second.
Data Upload	StartLater	Start logging at delayed start time.
	Stop	Stop logging or waiting to start logging. Press Enter key before entering command.
	GetSamples:b,e or DDb,e	Upload data from scan b to scan e .
Sampling	GetCast:x or DCx	Profiling mode only. Upload data from cast x .
	GetHeaders:b,e or DHb,e	Upload headers from header b to header e
	SL	Output last sample from buffer and leave power on.
	SLT	Output last sample from buffer, take new sample and store data in buffer. Leave power on.
	TS	Take sample, store in buffer, output data. Leave power on.
	TSS	Take sample, store in buffer and FLASH memory , output data, turn power off.
TSSon	Take sample, store in buffer and FLASH memory , output data, leave power on.	
	GetLastSamples:x	Output last x samples from FLASH memory.